Meet your new

VGN-B100 Series

Thank you for purchasing a Sony VAIO® computer! Your new computer is a superb blend of high technology and easy-to-use functionality. The information provided here is designed to help you to become familiar with your computer.

- **A** Main unit
- **B** Battery
- **C** AC Adapter
- **D** Power Cord



FRONT



REAR



BOTTOM



LEFT



RIGHT



2-541-670-01 © 2004 Sony Electronics Inc. All rights reserved. Printed in Japan.

1 Insert Battery



1. Unlock the UNLOCK/LOCK switch.
2. Insert the battery.
3. Lock the UNLOCK/LOCK switch.

2 Connect AC



3 Open Lid



4 Connect Mouse



* Mouse available separately.

5 Connect Headphones



* Headphones and speakers available separately.

6 Power On



SONY

Connect the Port Replicator

1 Turn off the computer and disconnect all attached devices.
2 On the bottom of the computer, slide the port replicator cover down until the port replicator connector is completely visible.
3 Align the sides of the computer with the sidewalls of the port replicator, and gently place the computer on top of the port replicator until it clicks into place.
4 Plug the AC adapter into the DC IN port on the port replicator, and plug the power cord into the AC adapter and an AC outlet.



* Port replicator available separately.

Use the Wireless

A wireless local area network (LAN) is a network in which you can connect through a wireless (radio) connection. You can opt to purchase a Sony Wireless LAN Access Point to set up a LAN.

1 Make sure an access point is set up. (See the instructions that accompanied the access point.)
2 Move the Wireless switch to ON.
3 Select the **Enable Wireless LAN** option in the Wireless Device Switch window, and click **OK**.
4 Click **Start** > **All Programs** > **VAIO Wireless Utility**.
5 Follow the steps provided by the VAIO Wireless Utility.


VAIO Wireless Utility
VAIO Assistant
Be taken step-by-step through the connection process.
Diagnostics
Check for issues preventing you from connecting to your wireless network.
Wireless Guide
View instructions for setting up a wireless connection.
Exit



Use the Internet





1 Locate the Modem jack on your computer.
2 Plug one end of the telephone cable into the Modem jack. Make sure it clicks into place.
3 Plug the other end into the wall jack.

Locate the User Guide

The online VAIO® Computer User Guide offers you more valuable information about your new computer. Once your computer is up and running, you can find the guide by following these instructions.

1 Click **Start** > **VAIO Help and Support**.
2 Under **Pick A Help topic**, click **VAIO User Guide**.





What do I do if my computer stops responding?

Although unsaved files may be lost, it is best to turn off your computer by following these steps:

Click **Start** > **Turn Off Computer** > **Turn Off**.

Alternatively, you may follow one or more of these suggestions to turn off the computer:

- Press the Ctrl+Alt+Delete keys simultaneously. Select the **Shut Down** menu, and click **Turn Off**. This option is particularly useful if your computer stops responding while you are playing a CD or DVD.
- Press and hold the power button until the computer turns off.
- Disconnect the AC adapter and remove the battery.

What do I do if my computer won't start?

The power indicator on the computer is off when the computer is not securely attached to a source of power. Make sure the computer is plugged into the AC adapter and the adapter is plugged into an outlet. If you are using battery power, make sure the battery is inserted properly and charged. You may check the power source by disconnecting the AC adapter and removing the battery. Wait one minute before reattaching the AC adapter and reinserting the battery. Additional suggestions include:

- If the computer is plugged into a power strip or uninterruptible power supply (UPS), make sure the power strip or UPS is turned on and working.
- If your computer is connected to an external display, such as a multimedia monitor, make sure the display is plugged into a power source and turned on. The brightness and contrast controls may need to be adjusted. See the guide that came with your display for more details.
- If the computer is starting from a floppy disk, eject the disk from the floppy disk drive (if applicable).
- If you notice condensation on the computer, do not use the computer for at least one hour. Condensation may cause the computer to malfunction.

To set up an Internet connection

1 Click **Start** > **All Programs** > **Accessories** > **Communications** > **New Connection Wizard**.
2 Click **Next**.
3 If it is not already selected, click **Connect to the Internet**.
4 Click **Next**.
5 Follow the on-screen instructions.


Internet Connection Wizard
Welcome to the Internet Connection Wizard
The Internet Connection wizard helps you connect your computer to the Internet. You can use this wizard to set up a new or existing Internet account.
I want to sign up for a new Internet account. (My telephone line is connected to my modem.)
I want to transfer my existing Internet account to this computer. (My telephone line is connected to my modem.)
I want to set up my Internet connection manually, or I want to connect through a local area network (LAN).
To leave your Internet settings unchanged, click Cancel.
To learn more about the Internet, click Tutorial.
Tutorial
< Back
Next >
Cancel

To register your computer

You are prompted to register your computer the first time you turn on the unit. Follow the on-screen instructions to complete the registration process. If you are not able to register your computer during the first session, you are provided with additional registration opportunities later. You can also register your computer online at http://www.sony.com/vaioregistration.

Take advantage of Sony's commitment to quality customer support and receive these benefits by registering your computer:

Sony Customer Support — Talk to a support representative to troubleshoot problems you may have with your computer.

Product Information Notification — By giving Sony your contact information, you will enable Sony to reach you regarding performance updates and upgrades.

Refer to the following Web sites for additional information about your computer.

- http://www.vaio.net
- http://www.sonystyle.com
- http://www.sony.com/pcsupport